

INSTALLATION INSTRUCTIONS FOR 96102116 LIGHT HARNESS REPAIR PLUG KIT

WHEN INSTALLING THE PLUG REPAIR KIT MAKE SURE TO USE THE REPAIR PLUG APPROPRIATE TO THE PLUG ON THE VEHICLE/HEADLIGHT THAT WILL BE REPLACED.

WHEN SPlicing THE NEW PLUG ON THE HARNESS, SLIDE THE SHRINK TUBE OVER THE WIRE FIRST, THEN USE THE INCLUDED BUTT CONNECTORS TO SPlice THE WIRES TOGETHER,

COVER THE BUTT SPlice WITH THE SHRINK TUBE AND HEAT TO SEAL THE SPlice. REPEAT FOR EACH WIRE. SEE DIAGRAM FOR WIRE COLOR COMBINATIONS. WHEN FINISHED, WRAP ALL CONNECTIONS IN ELECTRICAL TAPE.

REPLACES CONNECTORS TO HEADLAMPS

